

ADK187 DRY BLOCK KIT CARTRIDGE PLACEMENT

- 1. Remove Large *RED* cartridge (Water Valve) and replace with large *BLACK* cartridge (RPI Part #ADP189) supplied in kit.
- 2. Remove small *BLUE* cartridge (Check Valve) and replace the small *BLACK* cartridge (RPI Part #ADP188) supplied in kit.
- 3. Do not replace Brass top cartridge (Air Bleed Valve)

